

Asset Status and Heading

Each detected asset includes a Status Code and an Asset Heading that provide additional context about the detection.

The **Status Code** indicates the result of the identification process. A status of A0 typically indicates a successful, confident read. Other status codes may indicate partial reads, low-confidence detections, or exceptions that require manual review.

The **Asset Heading** describes the direction the asset was moving relative to the camera at the time of capture. For example, R2L means the asset was moving from right to left in the camera's field of view. This heading information, combined with the status tag (e.g., "Exiting"), helps operators understand the flow direction of assets at a gate or checkpoint.

The screenshot displays the SiteTrax.io web application interface. On the left is a navigation sidebar with options: Dashboard, Videos, Assets (selected), Reports, and Projects. The main content area is titled 'Assets / B540125'. It features an 'Asset Details' section with the following information:

- Asset ID: B540125
- Project: [Redacted]
- Scan Time: April 16th 2026, 8:33 am
- Asset Type: Trailer ID
- Processing Time: April 16th 2026, 8:42 am
- Status Code: A0
- Asset Heading: R2L

To the right of the details is an 'Asset Image' showing a white trailer at a checkpoint with a SiteTrax.io camera mounted on it. Below the image is an 'Asset Location' map snippet showing the area around 'SOUTH FONTANA Slover Ave' and 'Farmer Boys'.

Revision #3

Created 2026-04-08 17:46:58 UTC by SiteTrax.io Admin

Updated 2026-04-30 14:59:57 UTC by SiteTrax.io Admin